

Congratulations

Thank you for purchasing the UWaterK7 100% Waterproof Digital FM Radio. This Manual provides operation Instructions to help you enjoy listening to your most favorite FM stations while swimming, water sports, outdoors, any recreational activities. Enjoy Stereo Music, Talk, News or Sports anywhere you go world-wide. Please read Manual before using product.

Caution

1. Always screw down firmly the earphone plug onto Radio before entering the water. Do not unscrew or detach earphones while in the water. This Twist & Lock connection provides double protection. If water penetrated the Jack - rinse, dry out and reconnect earphones.

2. Radio complies with IEC 60529 IPX8 waterproofing standard and will not be damaged up to 3M (10FT) underwater. However, FM reception is available only at or above water surface, therefore, always keep earphone wires (which serve as antenna) at or over water surface.

PACKAGE INCLUDES: UWaterK7 Radio • Short Waterproof earphones • 2 sets of silicon Ear-Tips (M, L) • USB Cable • Owner's Manual/International Warranty

OPTIONAL ACCESSORIES: (available at www.fitnessstechusa.com) UWaterK7 Universal adapter (connect to any standard 3.5mm earphone or speaker) • Earphone Extension Cord • USB Wall Charger • USB Car Charger

1



No.	Name	Function Description
①	Tune Up	Manual/Auto Tuning Up
②	ON/OFF	Activation/Deactivation
③	Tune Down	Manual/Auto Tuning Down
④	Volume	Increase Volume/Set Memory/Select RCL
⑤	M/RCL	Set Memory & RCL modes
⑥	Volume	Decrease Volume/Confirm M set/Exit RCL mode

2

Quick Start Guide

A. **CHARGE** battery for at least 3 hours using the USB Cable. Ensure that the USB Cable plug is fully screwed in to Radio.

B. **POWER ON/OFF:** Long Press Control ② (5 seconds) for activation. Long press Control ② again for deactivation.

C. **TUNING:** Short press Control ① to tune up manually. Short press Control ③ to tune down manually. Long press (5 seconds) Control ② for auto tuning up (Receiver will automatically lock on the next STEREO station). Long press Control ③ for auto tuning down.

D. **VOLUME:** Short press Control ④ to increase volume. Short press Control ⑥ to decrease volume.

E. STATION MEMORY SETTING:

1. Select the designated station to be stored by tuning Controls ① or ③.

3

2. Long press (5 seconds) Control ⑤ until you see SET and the letter M Flashing.
3. Short press repeatedly Control ④ to select memory location (1-19)
4. Short press Control ⑥ to confirm selection. System will exit Memory Setting mode.

F. RECALL STORED STATION:

1. Short press Control ⑤ - LCD will indicate RCL
2. Short press Control ④ repeatedly to select stored station (1-19).
3. Short press Control ⑤ to exit Recall mode.

Radio Mounting

- Head Mounting (goggles or headband) is recommended for swimming - use short earphones.
- Connect earphones extension cable for arm/pocket or belt mounting.
- Two sets of Silicon Eartips are provided. It is recommended to use the long set for lap swimming.

4

Troubleshooting

Problem	Remedy
Unit is not charging	Verify that USB cable plug is fully screwed in to Radio. Verify that USB power source (computer, wall/car charger) is okay
Unit is not activated	Make sure unit is fully charged
There is no sound	Make sure unit is activated. Make sure Volume is correctly adjusted. Make sure earphones jack is properly connected to radio and is firmly screwed down. If you are in the water make sure water did not penetrate your ear canal and block sound
Can't exit M setting mode	Short press Control 6
While swimming, sound is weak	Check if water penetrated your ear canal. Dry earphones out then adjust eartip mounting or use longer eartips

For additional information, check our website: www.fitnessstechusa.com

5

Specifications / Features

- Waterproof Rating: IPX8
- FM Reception: 88-108 MHz
- Auto/Manual Tuning
- Li-Ion rechargeable Battery
- 2-3 Charging Time/6-8 HRS Continuous usage/Single Charge
- 19 Preset Memories Capacity
- USB 2.0 High Speed
- Dimensions: 1.5 x 1.75 x 0.5
- Weight : one ounce



www.fitnessstechusa.com

6