



200% Waterproof Universal Soft Case

OWNER'S MANUAL



ACTION AUDIO FOR ACTIVE LIFESTYLES

www.gearedtobefit.com



Introduction

The Uwater 200% Waterproof Universal Soft Case sports a dual sealing system so you can protect your personal electronics - Smartphone, Player, Camera – and your personal belongings - Wallet, Passport, Credit Cards, Keys - with utmost confidence in any outdoor wet environments.

The dual (x2) sealing system comprises a lockable linear seal plus a Sliding Security Clip.

Using Your UWater 200% Waterproof Universal Soft Case

Caution:

Product was tested at factory; however, you must test yourself prior to usage:

1. Remove protective film from both sides of the Soft Case.
2. Insert dry paper (or towel paper) into soft case.
3. Firmly lock the linear seal using the Slide-Locker. Start from one edge, ensure that the linear seal is completely locked.
4. Fold the top and fasten the Sliding Security Clip.
5. Submerge the soft case in water for 30 min.
6. Manipulate the soft case during submersion.
7. Remove from water and fully dry exterior.
8. Open the soft case and verify that paper is completely dry and there is absolutely no water inside. **If water is found inside the soft case, immediately return to seller.**
9. **Inserting Phones:** Slide in your phone all the way to bottom of the soft case. For easier usage remove your hard case. Repeat instructions 3 and 4 above.
10. Connect rope.

Maintaining Your UWater Waterproof Universal Soft Case


Always check and test your UWater soft case before use to make sure it was not damaged during your last activity. Do not expose it to extreme heat, such as the inside of a hot car.

After in-water use, rinse off your UWater soft case with clean water and let it air dry for your next use. Detergents, soaps, and chemicals must never be used to clean this product.

For long-term storage, store out of direct sunlight.



Do not use silicone grease or any grease to lubricate this product.

COMPONENTS For Phone



HOW TO USE

Test the soft case:
See the opposite page
steps 2 through 8



**Fitness
Technologies**

ACTION AUDIO FOR ACTIVE LIFESTYLES
www.gearedtobefit.com

Limited Warranty

Fitness Technologies' waterproof soft cases are warranted against defects in materials and/or workmanship for 60 days from the date of original purchase. This limited warranty does not apply to any soft cases which have been neglected, altered, abused, used for a purpose other than the one for which they were manufactured, altered by customers or any party, or used in any manner inconsistent with Fitness Technologies' written instructions. This limited warranty is not valid for soft cases purchased through an unauthorized source. This limited warranty covers only Uwater Soft Cases and is not valid in connection with any other product.

During the Warranty period, Fitness Technologies will, at its sole discretion and at no cost to customer, repair or replace any soft case that fail in normal use.

Customer will be responsible for the cost of shipping the soft case to Fitness Technologies. Fitness Technologies will pay the cost of returning the repaired or replacement soft case to the customer. **IN NO EVENT WILL FITNESS TECHNOLOGIES LIABILITY TO CUSTOMER EXCEED THE PURCHASE PRICE OF THE SPECIFIC SOFT CASE SUBJECT TO THE WARRANTY CLAIM.**

Fitness Technologies reserves the right to replace any out-of-stock, discontinued, or limited edition product with a comparable product. Discontinued products may not be available for warranty replacement

For warranty service please obtain Return merchandise Authorization (RMA) at this link:

http://www.gearedtobefit.com/rma_request_form.cfm and follow instructions accordingly.

Warranty Card Number: **SC52574M**

Please allow 3-4 weeks for processing.

If you have any questions please contact us at: info@fitnesstechusa.com

Hackensack, NJ 07601 USA

Patent pending